

# Tusk Low Profile UTV Mirror Roll Cage Clamp & Tusk Pivot Mirrors



**TUSK**

The Tusk Low Profile Roll Cage Clamp is the perfect solution for the side view mirror mounting as well as other accessories where a thin clamp is required. This mount allows for mounting accessories where roofs and windows are already in place.

**Assembly:** *Before you throw any packaging away, make sure you received all the necessary hardware:*

## CONTENTS:

Tusk Pivot Folding Mirror (2)  
Tusk Low Profile Mirror Clamp (2)

## Passenger Side



## Quantity 2



## Installation Instructions

Depending on the kit you have chosen, you might receive different mirrors than illustrated in these instructions. The steps outlined to mount mirrors and clamps to your machine will be same. Throughout the installation process refer to the images below for reference.

1. Locate a desired section of roll cage that best fits your needs for your side view mirrors.
2. Spread the clamp over the "A" pillar roll cage section. Install the spacer between the clamp with the foam piece facing towards the roll bar as shown.
3. Install the mirror using the included bolt with the clamp. Sandwich the serrated washer between the mirror and the Tusk Low Profile UTV Mirror Clamp as shown below.

**Congratulations! You've now installed your new Tusk Low Profile UTV Mirror Clamps!**



INSTALLATION INSTRUCTIONS AND INFORMATION